## **HOMEBUILDER**

Daytek.


Design for Today

ASSEMBLY INSTRUCTION




<u>CAUTION!</u> – INFLATE TYRE WITH CARE. DO NOT EXCEED RECOMMENDED PRESSURE. ENSURE SQUARE NECK OF BOLTS ARE LOCATED IN BOWL DURING ASSEMBLY.

<u>TIP</u> – PLACE STRONG TAPE OVER THE HEAD OF THE BOLTS TO HOLD THEM IN POSITION DURING ASSEMBLY. USE A MALLET TO KNOCK COMPONENTS INTO POSITION IF NEEDED.





- 1. PLACE WHEELBARROW BOWL UPSIDE DOWN OVER A BENCH OR TABLE EDGE.
- **2.** ASSEMBLE HANDLES "A" INTO FRONT FRAME "B" AS PER DIAGRAM. LOCATE ASSEMBLY OVER THE HOLES IN THE BOWL. INSERT 2 x LONG BOLTS FROM INSIDE THE BOWL AT POSITION 1 AND FINGER TIGHTEN WITH WASHERS & NUTS.
- **3.** ASSEMBLE LEGS " $\mathbf{C}$ " TOGETHER IN A CROSS-PATTERN AT POSITION 2 WITH 1 x SHORT BOLT AND <u>FINGER TIGHTEN</u> WITH WASHER & NUT.
- **4.** LOCATE THE LEGS OVER THE BOWL AS SHOWN AND FIX WITH 4 x LONG BOLTS AT POSITION 3 & 4. <u>FINGER TIGHTEN</u> WITH WASHERS & NUTS.
- 5. ASSEMBLE THE 2 STRUTS "D" TO THE FRONT OF THE BOWL AND FINGER TIGHTEN ONLY.




## **HOMEBUILDER**

Daytek.

ASSEMBLY INSTRUCTION

## FITTING THE WHEEL

- 6. INSERT AXLE THROUGH THE WHEEL HUB.
- 7. SLIDE AXLE SPACER OVER EACH END OF AXLE. ENSURE AXLE AND SPACER ARE POSITIONED CENTRAL IN THE HUB.
- **8.** LOCATE ONE AXLE BRACKET AT POSITION 5 ON FRONT FRAME "**B**". INSERT 1 x LONG BOLT THROUGH STRUT, AXLE BRACKET AND FRAME. TIGHTEN WITH WASHER & NUT AS SHOWN IN DIAGRAM BELOW.
- **9.** INSERT ONE END OF AXLE AND WHEEL ASSEMBLY INTO THE AXLE BRACKET. ENSURE THE FLAT EDGE ALIGNS WITH THE FORM OF THE AXLE BRACKET.
- **10.** SLIDE THE SECOND AXLE BRACKET INTO POSITION ON THE OTHER SIDE OF THE FRAME. ALIGN THE AXLE TO ENSURE IT SLOTS INTO POSITION AT THE SAME TIME.
- 11. SECURE STRUT, AXLE BRACKET AND FRAME WITH 1 x LONG BOLT AND TIGHTEN WITH WASHER & NUT.
- 12. CHECK OVER ENTIRE ASSEMBLY, FULLY TIGHTEN ALL BOLTS AND ENSURE THAT THE WHEEL IS FREE TO SPIN.



Manufactured/Supplied by Daytek Australia Pty. Ltd.

77-81 Gower Street, Preston, Victoria 3072 Australia T +61 3 9470 1755 F +61 3 9470 5381

For more details on the Daytek range of products please visit our website

daytek.com.au



